

Toestellen

DP750/DP760 LED lampjes

Dit zijn de lampjes op de DP750 en DP760 en wat ze betekenen.

LED	Status
	Indicates Power ON/OFF.
	Indicates access to the network. <ul style="list-style-type: none">• Solid ON: When there is access to the network.• Blinking: If there is no access to the network.
	Indicates status of the association between DP760 and DP750 <ul style="list-style-type: none">• Blinking: When the DECT station is scanning for available RFPs.• Solid ON: When the association between DECT repeater and Base station is operational.
	Indicates status of the association between DP760 and DP750 during calls. <ul style="list-style-type: none">• Solid ON: When there are no active calls and the association between DECT repeater and Base station is operational.• Blinking: During active calls.
	Indicates status of the association link between the DP760 and DP750. <ul style="list-style-type: none">• Solid ON: When the association between DECT and Base station is operational, and link is excellent.• Blinking:<ul style="list-style-type: none">▪ Long ON, 1x short OFF if the association link is good.▪ Long ON, 2x short OFF if the association link is weak.▪ Long ON, 3x short OFF if the association link is poor

Afkortingen

- RFP - Radio Fixed Part Identity

Unieke FAQ ID: #1484

Auteur:

Laatst bijgewerkt: 2018-12-17 15:21